

140-1000 FlexiStore™ Dispenser Kiosk

Our Dispenser Kiosk is a PETG/HDPE stand designed to present one of our compatible dispensers to promote hygiene and to provide greater availability of related supplies.

Recommended Tools: Phillips head screwdriver

Installation Instructions

1. Your kiosk came with 4 self-stick furniture pads to protect polished floors. If your locating the kiosk on a carpeted floor, you can skip this step. Taking care not to scratch or damage the dispenser, attach the 4 furniture pads to the underside of the kiosk's base.
2. Your kiosk came with 2 screws to attach a compatible dispenser. Locate the 2 screws and insert them into the 2 matching holes on the bottom of the dispenser.
3. Holding the dispenser slightly above the kiosk, align the 2 screws with the corresponding holes on the top of the kiosk and give each screw a few turns to confirm proper alignment.
4. Tighten the screws to draw the dispenser flush with the top of the kiosk — but don't fully tighten the screws at this point.
5. Verify that the dispenser is centered on top of the kiosk.
6. Once you've confirmed the dispenser is centered on the kiosk, fully tighten both screws. **Be careful not to over-tighten the screws so as not to crack the PETG material.**
7. Completely remove the clear protective outer film from both the dispenser and the kiosk.
8. Take pride in a job well done!

Cleaning Instructions

To clean our PETG-based products, the best approach is to use warm, soapy water. A 3 - 5% solution of hydrogen peroxide or a 70% solution of isopropyl alcohol can also be used to clean PETG without risk of damage to the dispenser. Diluted household bleach (1/3 cup of bleach per 1 gallon of water) from a supply made weekly is also safe; diluted bleach is not stable for long periods of time. Do **NOT** use harsh disinfectants such as Lysol, Shockwave, or ZEP. Do **NOT** use cleaning fluids with acetone, ammonia, carbon tetrachloride, denatured alcohol, or gasoline. To reduce the risk of scratching the surface of the dispenser, only use a soft cloth for cleaning. Like most plastics, PETG can be easily scratched by steel wool or abrasive sponges; therefore, do **NOT** use abrasive wipes or sponges on your dispenser.

Product Warranty

Subject to normal use consistent with the installation and cleaning instructions supplied with this product, we warrant that it shall be free from defects for a period of one (1) year from the date of purchase. Should the product exhibit a defect during this one (1) year period, upon confirmation of the defect, we in our sole and absolute discretion will repair or replace it at our expense. Purchaser is responsible for all return shipping costs, if any. Our liability is strictly limited to the cost of repairing or replacing the product with a similar product in new condition. Our liability does **NOT** include consequential, special, incidental, or indirect damages in any form or amount.

To file a warranty claim, please visit <https://www.brandedsafety.com/warranty/>