

# ARG6PV-AFZ5PVBIADASTACK



64" x 23.38" x 25" (H x W x D)

PHARMA-VAC Performance Series stacked combination of ARG6PV vaccine all-refrigerator and AFZ5PVBIADA manual defrost all-freezer

## Highlights:

Purpose-built design to store medication, pharmaceuticals, and other sensitive materials

Independent refrigerator and freezer storage in one slim-fitting footprint for space-challenged facilities

Intelligent microprocessor digital temperature controller for optimum temperature management

## Product Features:

Performance Series Refrigerator-Freezer Combination	Purpose-built all-refrigerator and all-freezer for vaccine storage in medical, pharmaceutical, and life science applications
Purpose-built design	Designed and purpose-built for pharmacy, medication, and vaccine applications to support meeting CDC/VFC/VFA guidelines
+/-1°C Variation	The published temperature variation is derived from the maximum deviation of an NTC sensor in a 1 oz. vial located nearest the chamber geometric center during a 24 hour test period
Space-saving design	Allows you to create a full refrigerator-freezer with independent controls in a slim-fitting footprint
Easy assembly	Unit ships in three boxes for customer to install the StackRack on the bottom refrigerator/freezer and place and secure the other unit on top
Antimicrobial silver ion-coated handles	Powder-coated handles with naturally occurring silver ions to help reduce the spread of germs
Adjustable temperature	Intuitive controls let you adjust the interior temperature between +2 to +8°C (refrigerator) and -30° to -10°C (freezer)
Temperature alarms	Visual and audible alarms alert if the interior temperature rises or falls out of set range

## ARG6PV-AFZ5PVBIADASTACK Specifications:

Overview		Freezer - Interior Depth	18.0" (46 cm)
Nominal Height	64.0" (163 cm)	Freezer - Capacity	3.88 cu.ft
Height of Cabinet	64.0" (163 cm)	Freezer - Shelf Type	Wire
Nominal Width	24.0" (61 cm)	Freezer - Shelf Qty	4
Width	23.38" (59 cm)	Thermostat Type	Digital
Width with Door Open	23.88" (61 cm)	Fan Type	Interior
Nominal Depth	25.0" (64 cm)	Freezer - Temperature Range	-30 to -10°C
Depth	25.0" (64 cm)	Freezer - Refrigerant Type	R290a
Depth with Handle	26.75" (68 cm)	Freezer - Refrigerant Amount	1.73 oz.
Depth with door at 90°	47.0" (119 cm)		
Capacity	9.88 cu.ft. (280 L)		
Door	Glass		
Cabinet	White		
US Electrical Safety	ETL		
Canadian Electrical Safety	ETL-C		
Voltage/Frequency	115 V AC/60 Hz		
Parts & Labor Warranty	2 Years		
Compressor Warranty	5 Years		
UPC	761101104140		
Refrigerator-Freezer			
Door Swing	RHD		
Reversible	Factory Reversible		
Adjustable Shelves	Yes		
Interior Light	Yes		
Refrigerator - Interior Height	24.5" (62 cm)		
Refrigerator - Interior Width	20.0" (51 cm)		
Refrigerator - Interior Depth	17.0" (43 cm)		
Refrigerator - Capacity	6.0 cu.ft		
Refrigerator - Shelf Type	Wire		
Refrigerator - Shelf Qty	4		
Refrigerator - Temperature Range	2 to 8°C		
Refrigerator - Refrigerant Type	R600a		
Refrigerator - Refrigerant Amount	1.66 oz.		
Freezer - Interior Height	22.5" (57 cm)		
Freezer - Interior Width	18.0" (46 cm)		