

# VT65MLBIIFADA



32.25" x 23.63" x 23.5" (H x W x D)

ADA compliant built-in medical all-freezer with lock, capable of -25° C operation; door accepts fully overlay panels

**Highlights:**

32 inch height fits under lower ADA compliant counters

Flexible design allows built-in or freestanding use

Door can accept custom panels to seamlessly blend into cabinetry

**Product Features:**

ADA Compliant	32 inch height is designed to fit under ADA compliant counters
Built-in capable	Front-breathing design lets you make the best use of space by installing your appliance under the counter
Fully finished white cabinet	Allows the unit to be used freestanding
Factory installed lock	Keep contents secure with a front lock on the door
Integrated door frame	Customize the front by mounting an overlay panel over the door; seamless look can blend into cabinetry with no exposed frame. Handle not included. (panel dimensions: 23 5/16" W x 28 1/4" H and at least 3/4" thick; maximum weight: 10 lbs.)
-25° capable	Low temperature operation is ideal for vaccine, pharmaceuticals, and other temperature sensitive materials
Manual defrost	Energy efficient operation
Three slide-out drawers	Conveniently organize your items while keeping the temperature stable when the door is opened
No internal fans	Static cooling system

## VT65MLBIIFADA Specifications:

Overview	
Nominal Height	32.0" (81 cm)
Height of Cabinet	32.0" (81 cm)
Height to Hinge Cap	32.25" (82 cm)
Nominal Width	24.0" (61 cm)
Width	23.63" (60 cm)
Nominal Depth	24.0" (61 cm)
Depth	23.5" (60 cm)
Capacity	3.5 cu.ft. (99 L)
Defrost Type	Manual
Door	Panel-Ready
Cabinet	White
US Electrical Safety	UL
Canadian Electrical Safety	ULC
Amps	1.3
Voltage/Frequency	115 V AC/60 Hz
Weight	105.0 lbs. (48 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101043449
Freezer	
Door Swing	RHD
Reversible	Factory Reversible
Crisper Finish	Opaque
Crisper Cover	Glass
Interior Height	24.25" (62 cm)
Interior Width	17.75" (45 cm)
Interior Depth	16.5" (42 cm)
Shelf Type	Glass
Thermostat Type	Digital
Refrigerant Type	R134a
Refrigerant Amount	2.7 oz.
High Side PSI	235.0
Low Side PSI	70.0
Level Legs	4
Interior Drawers	Yes
Drawers Qty	3
Compressor Step Height	6.0" (15 cm)

Compressor Step Width	17.0" (43 cm)
Compressor Step Depth	6.0" (15 cm)
Temperature Range	-12°C to -25°C

