



WATER FILTERS

FILTRATION SYSTEMS

WATER FILTERS

07/17/25

Item # 13076

Item #: _____

Project: _____

Qty: _____

AIA#: _____

H9320 FILTER

Single, Double, Triple



H9320-51

Single Configuration
18.4" H*



H9320-52

Double Configuration
19.11" H*



H9320-53

Triple Configuration
19.15" H*

*height includes manifold and cartridge

HOSHIZAKI H9320 FILTER

Available in single, double and triple configurations. Rated NSF Class 1, STD 42, for taste, odor and chlorine reduction and for mechanical filtration (95.6% removal of particles one (1) micron and larger in size.)

- Keep ice makers functioning at full capacity
- 97.3% average reduction of chlorine from incoming water supply, eliminating tastes and odors of the ice
- Filters are rated as one (1) micron nominal producing crystal clear ice
- Decrease machine maintenance by reducing lime scale build-up

Model	Filter	Max Flow Rate	Working Pressure	Temperature	Capacity
H9320-51	4HC-H	2 gpm	10-125 psi	35-100°F	21,000 gal
H9320-52	4HC-H	4 gpm	10-125 psi	35-100°F	42,000 gal
H9320-53	4HC-H	6 gpm	10-125 psi	35-100°F	63,000 gal

Plumbing

Inlet/Outlet Connections: Single: (2) 3/8" FNPT

Double & Triple: (1) 3/4" MNPT / (1) 3/4" FNPT

The H9320 Filters and their respective cartridges have been tested and listed by NSF only for the functions listed above. Check for compliance with state and local laws and regulations. Do not use where the water is microbiologically unsafe, or with waters of unknown quality without adequate disinfection before or after the unit. The H9320 filter can be used with water that may contain filterable cysts.



The H9320 System is tested and certified by NSF International against NSF/ANSI Standard 42 for the reduction of:

Std. No. 42 - Aesthetic effects

Aesthetic Effects

Bacteriostatic Effects

Chemical Reduction

Chlorine

Mechanical Filtration

Nominal Particulate Class 1

Taste & Odor

E-10 PREFILTER

(9795-80)

E-20 PREFILTER

(9795-90)



**E-10
PREFILTER**
(9795-80)

Recommended for
single configuraton



**E-20
PREFILTER**
(9795-90)

Recommended for
twin and triple
configuration

E-10 and E-20 Prefilters can be used for ice. Everpure prefilters are designed to increase the life of Hoshizaki 4HC-H water filters in areas with an unusual amount of dirt in the water. With a 10 micron (nominal) rating, the economical Everpure prefilter traps much of the dirt which contributes to scale buildup in ice makers, and clogs the delicate orifices of other water-using equipment.

When you install an Everpure prefilter, the Hoshizaki 4HC-H water filters can concentrate on what they do best: remove particles one (1) micron nominal and larger in size.

Replacement Cartridges:

E-10 Prefilters: 12 pack (9534-12)
40 pack (9534-40)

E-20 Prefilters: 6 pack (9534-26)
20 pack (9534-20)



Warranty:

One Year replaceable elements*

One Year the entire system

* Warranty applies to material defects in materials & workmanship only.

Hoshizaki reserves the right to change specifications without notice.