

accucold

Professional Cold Storage

Precise • Stable • Efficient • Whisper Quiet

Designed and Purpose-Built for

PHARMACY • MEDICAL • LIFE SCIENCE
LABORATORY • PHARMACEUTICAL • BIOTECH



MOMCUBE® Series Breast Milk Refrigeration

All-refrigerators specially designed for the unique needs of breast milk, with interior locking compartments to allow nursing mothers private storage



Countertop



ADA



Undercounter



Full Sized



Purpose-Built for Breast Milk Storage

Designed to operate between 33 and 40°F for the proper storage of human milk
Individual locking compartments for secure, separate storage for ("LK" Series)
Combination locks allow each mother her own access system
Single key override included for staff to manage as needed
Audible/visual alarms for high/low temperature excursions
Open door alarm offers added assurance in office or hospital settings



Advanced Temperature Performance

Intelligent microprocessor digital temperature controller
Improved accuracy with a buffered probe in glycol-filled bottle to simulate temperature of stored bottles
Additional sensor reads interior air temperature for superior temperature control
Digital display of the min/max temperature (updated in 15 minute increments)
Password protection of control parameters beyond setpoint
Optimized forced air cooling for excellent temperature stability



Fully Featured Interior For Convenient Storage

Energy efficient LED lighting with internal on/off switch
½" probe port included to accept user-provided monitoring equipment



Quality Design For Reliable Performance

Hospital grade cord with a green dot plug
Antimicrobial silver ion-coated handle for added protection from germs
Self-closing door offers added storage protection
Environmentally friendly natural hydrocarbon refrigerant for reduced global warming potential
Meets EPA and SNAP requirements
Convenient security with a top-mounted front door lock (2 keys included)
Powerful magnetic door gaskets to ensure a tight seal for energy savings and improved performance



SKU: ARS8MLMCLK

MOMCUBE Freezers:

Provide additional solutions for longer term storage.
 These units come with a more basic featured package.



Interior locking compartments allow private storage



Designed to maintain recommended temperature for breast milk storage



Technical Specifications (Refrigerators*):

Defrost type: Cycle
Thermostat: Intelligent microprocessor digital
Temperature sensors: 2 (air probe & buffered probe)
Adjustable operating control range: 33 to 40°F
Temperature variation: +/-1.8°F*
Shelving: Interior locking compartments or adjustable white plastic coated wire
Voltage: 115V/60Hz
Cord: NEMA 5-15P
Lock: Factory-installed key lock + individual combination locks with single key override ("LK" Series)
Refrigerant: Eco-friendly R600a
Light: LED

SPRF11MC

ARS6MLMC

ARS8MLMCLK

ARS15MLMCLK

Access Port: 1/2"
Door: Reversible
Fan: Internal
Certifications: ETL, ETL-C
Parts & Labor Warranty: 2 years
Compressor Warranty: 5 years

Included with units:
2 keys for outer door
2 keys to override combination locks
User manual

DESIGNED TO PROVIDE +/-1.8°F VARIATION

The published temperature variation is derived from the maximum deviation of an NTC sensor in a 1 oz. vial located nearest the chamber geometric center during a 24 hour test period.



Extended Warranty

2-year parts & labor
5-year compressor



Eco-Friendly

Uses environmentally friendly hydrocarbons for a greener footprint



Logging Option

DDLs available for cloud or USB-based outputs



LOCKERS

Individual storage compartments with combination locks

Refrigerators

	SKU	CAPACITY	H x W x D	INSTALLATION	DOOR	CABINET	INTERIOR	AMPERAGE	SHIPPING WT.
🔒	ARS1MLMC	1 cu.ft.	21.5" x 17.5" x 19.75"	Freestanding	White	White	2 shelves	0.6	70 lbs
🔒	ARS2MLMC	1.94 cu.ft.	22.25" x 18.5" x 23.25"	Freestanding	White	White	2 shelves	0.6	86 lbs.
🔒	ARS3MLMC	3 cu.ft.	34" x 18.5" x 19"	Freestanding	White	White	4 shelves	0.6	90 lbs
🔒	ARS32MLMCBIADA	2.83 cu.ft.	32" x 23.38" x 22.63"	Recessed	White	White	4 shelves	0.6	113 lbs
🔒	ARS6MLMC	6 cu.ft.	32.5" x 23.38" x 24.63"	Freestanding	White	White	4 shelves	0.75	120 lbs
🔒	ARS6MLMCLK	6 cu.ft.	32.5" x 23.38" x 24.63"	Freestanding	White	White	2 locking compartments	0.75	150 lbs
🔒	ARS62MLMCBIADA	6 cu.ft.	32" x 23.38" x 25"	Recessed	White	White	4 shelves	0.75	150 lbs
🔒	ARS62MLMCBIADADLK	6 cu.ft.	32" x 23.38" x 25"	Recessed	White	White	2 locking compartments	0.75	150 lbs
🔒	ARS8MLMC	8 cu.ft.	50" x 23.38" x 24.38"	Freestanding	White	White	7 shelves	1.4	170 lbs
🔒	ARS8MLMCLK	8 cu.ft.	50" x 23.38" x 24.38"	Freestanding	White	White	2 locking compartments	1.4	210 lbs
🔒	ARS12MLMC	12 cu.ft.	61.75" x 23.38" x 24.38"	Freestanding	White	White	7 shelves	1.4	185 lbs
🔒	ARS12MLMCLK	12 cu.ft.	61.75" x 23.38" x 24.38"	Freestanding	White	White	6 locking compartments	1.4	230 lbs
🔒	ARS15MLMC	15 cu.ft.	72" x 23.38" x 24.38"	Freestanding	White	White	7 shelves	1.4	215 lbs
🔒	ARS15MLMCLK	15 cu.ft.	72" x 23.38" x 24.38"	Freestanding	White	White	8 locking compartments	1.4	300 lbs

Freezers

	SKU	CAPACITY	H x W x D	INSTALLATION	DOOR	CABINET	INTERIOR	AMPERAGE	SHIPPING WT.
🔒	AFZ1PVMC	1.5 cu.ft.	22.25" x 18.5" x 23.25"	Freestanding	White	White	1 shelf	1.3	86 lbs.
🔒	AFZ2PVBIADAMC	2.47 cu.ft.	32" x 19.75" x 22.63"	Recessed	White	White	4 shelves	1.3	110 lbs.
🔒	AFZ5PVBIADAMC	3.88 cu.ft.	31.75" x 23.38" x 25"	Recessed	White	White	4 shelves	1.3	165 lbs.
🔒	AFS14PVMC	9.53 cu.ft.	74.38" x 23.5" x 25.25"	Freestanding	White	White	6 shelves	4.6	280 lbs.
🔒	AFS17PVMC	14.83 cu.ft.	79.5" x 27.5" x 26.63"	Freestanding	White	White	6 shelves	4.6	300 lbs.

Portable Refrigerator/Freezer

	SKU	CAPACITY	H x W x D	FINISH	POWER	TEMPERATURE RANGE	SHIPPING WEIGHT	SHIPPING WT.
	SPRF11MC	.35 cu.ft.	11.25" x 14" x 16.13"	White	12/24V DC/115V	-20 to +8°C	17 lbs.	37 lbs